

**BLUE LAKE SPRINGS MUTUAL WATER COMPANY**  
**P. O. Box 6015 Arnold, CA 95223**  
**(209) 795-7025**

**RULES AND REGULATIONS for NEW CONNECTIONS**

**APPLICATION FOR SERVICE:**

Prior to any use of water, an Application for Service must be made with this office. **NO TEMPORARY WATER CONNECTIONS WILL BE PERMITTED!**

**SERVICE CONNECTION:**

A fee for the service connection and installation shall be paid with the application per fee schedule in effect at the time of application. No service connection will be made until plans have been approved.

**FEE:**

\$7,131.00 service connection and installation fee; includes construction water.

**WATER FEE:**

Cabin water fees for the current year will be charged on a prorated basis, commencing with the first of the month following date of connection.

**APPLICATION AND FEE FOR EXCESS WATER USE: (sprinkler system, drip systems, soaker hoses, spas, mister, spikes, hoses laid down to run, etc.)**

Plans must be submitted and comply with the Rules and Regulations of the Blue Lake Springs Mutual Water Company relating to cross-connections, and then a meter must be installed. The current fee for meter installation is \$140.00.

**SERVICE PIPE:**

All service pipe, furnished and installed by the plumber, shall comply with the following Calaveras County requirements and it shall be installed in accordance with the manufacturer's instructions, to a depth of no less than 12 inches.

- a. Copper, type "K" or "L"
- b. PVC commercial standard C.S. 256-63, Schedule 40
- c. Galvanized iron, Schedule 40

All service pipe shall be covered and have a shut off valve in the closed position, installed at the cabin, before a connection can be made. The pipe to extend to the service box with enough pipe to drape over the box to make the connection. **THE WATER COMPANY WILL DIG UP THE BOX!**

A standpipe will be allowed if it is installed a minimum of 20 feet from the service box and an Application for Service is made. The service pipe shall not be installed in or over the leach field or the septic tank.

**PRESSURE REDUCING VALVE:**

The service shall be equipped by the owner with a pressure regulator set to 60 psi. The regulator shall be installed, owned, and maintained by the owner and at owner's expense. The regulator shall be on the owner's side of the service.

The water company will install a Pressure Reducing Valve at the service box. All owners shall be required to accept such conditions of water pressure and service as are provided by the distribution system at the point of connection, and the Blue Lake Springs Mutual Water Company shall not be liable for any damage arising from high or low water pressure.

**RELIEF VALVE:**

A check valve will be installed by the water company at the service box to insure against back siphoning. Temperature and pressure relief valves are required on all closed water heating systems.

**SEPTIC SYSTEMS:**

The septic tank or leach field shall not be installed closer than 10 feet from any existing water main. (Article 5, Section 64630, California Health and Safety Code)